R181F - HOLKHAM DOWN FEEL JACKET



Measures in CMS

| | SIZE | | | | | | | TOL |
|---|--|----|----|----|----|----|-----|-----|
| | OIZL | XS | S | M | L | XL | 2XL | +/- |
| Α | 1/2 CHEST - AT UNDERARM - LAY JACKET OUT FLAT | 54 | 56 | 58 | 60 | 62 | 64 | 1 |
| В | BACK LENGTH | 65 | 66 | 67 | 68 | 69 | 70 | 1 |
| С | SLEEVE LENGTH FROM SHOULDER SEAM | 60 | 61 | 62 | 63 | 64 | 65 | 1 |

